



Children should never be left unsupervised. Adults should always be on their guard.



The Finger Alert Door Stopper cannot prevent fingers from getting caught in the hinge side of the door.



Removing the 3M tape may cause damage to surface finishes and paintwork.